



Get to Know Your Phone

Setting Up Your Phone

Welcome to Verizon Wireless. You're now part of a growing movement that's about speed, signal and strength. This guide will show you how to set up and use your phone, access special features, and find help.


Step 1. Remove the Back Cover

Place your fingernail in the cutout at the bottom of the phone and pop the cover off the phone.



Step 2. Insert the Battery

Insert the battery, making sure to align the gold contacts. Press down gently to secure the battery.



Step 3. Replace the Back Cover

Place the back cover over the back of the phone and press down along the edges to secure it.



Step 4. Charge the Phone

Before turning on your phone, charge it fully.

1. Connect the USB cable to the charger adapter.
2. Plug the other end of the USB cable to the Charging/USB port and the charger adapter into an electrical outlet.

CAUTION! Please use only an approved charger to charge your phone. Improper handling of the charging port, as well as the use of an incompatible charger, may cause damage to your device and void the warranty.




Optional: Insert the microSD™ Card

If you have a microSD card, open the microSD card slot and slide the microSD card into it (as pictured below).

NOTE: The microSD card is sold separately.



- | | |
|--------------------------|----------------------------|
| 1 3.5 mm headset jack | 7 Return key |
| 2 Earpiece | 8 Clear key |
| 3 Shortcuts button | 9 Send key |
| 4 QWERTY keyboard | 10 Back/Voice Commands key |
| 5 Function/Favorites key | 11 Power/End key |
| 6 Shift/Messaging key | 12 Quick keys |



- | | |
|---------------------|---------------------|
| 1 Camera | 5 Charging/USB port |
| 2 Speaker | 6 Camera/Video key |
| 3 Volume keys | 7 Lock key |
| 4 microSD card slot | |

NOTE: Devices and software are constantly evolving so the screen images and icons on your device may differ slightly from what is shown here.

Using Your Phone

Turning Your Phone On/Off

 Press and hold the **Power/End** key to turn your phone on. Then swipe your finger across the screen in any direction to unlock it.

 Press and hold the **Power/End** key to turn your phone off.

Home Screen



Making a Call

 Tap the **Phone** icon to open the dial pad and enter the phone number.

 Tap **CALL** or press the **Send** key to dial the number.

 Press the **Power/End** key to end the call.

 Your phone has a Voice Commands feature that also lets you make calls by saying a phone number or Contact name. To access it, press the **Back/Voice Commands** key and say **Call** followed by the name or number.

Receiving a Call

 When the phone rings or vibrates, simply press the **Send** key or tap **ANSWER** to answer the call.

 Tap **QUIET** to mute the ringing or vibration for the call.

 Tap **IGNORE** to ignore the call and send the caller directly to voice mail.

 Tap **TEXT** to ignore the call and send a quick text message.

 Press the **Power/End** key to end the call.

Locking/Unlocking the Phone

The touch screen is automatically locked when the backlight is off.

 Press the **Lock** key to lock or wakethe screen. Then swipe your finger across the screen in any direction to unlock it.

Setting Up Voice Mail

1.  Tap the **Phone** icon to open the dial pad. Then dial ***86**.
2.  Tap **CALL** or press the **Send** key.
3. Then follow the setup instructions.

Checking Voice Mail

From your phone:

 Tap the **Phone** icon to open the dial pad. Then dial ***86**.

 Tap **CALL** or press the **Send** key. Then follow the instructions.

From other phones:

1. Dial your wireless number.
2. When you hear the greeting, press **#** to interrupt.
3. Follow the instructions.

NOTE: Voice mailboxes not set up within 45 days will be canceled. Your voice mailbox is not password protected until you create a password by following the setup instructions.

Sending a Text

1. Slide out the QWERTY keyboard.
2.  Tap the **Messaging** icon. Then tap **New Message**.
3. Tap **Enter New** and enter the phone number or email address of the recipient.

Then tap **Done**. (You can enter up to 20 addresses for a single message.)

4. Tap the **Add Text** field and enter your message.
5. Tap **Done** and then **Send** to send your message.

Taking Photos

1.  Press the **Camera** key.
2.  Focus on your subject and tap **Take** on the screen or press the **Camera** key to take a picture.
3. After taking the picture, tap one of the following options:
 - **Erase** to erase it.
 - **Save** to save it to My Pictures.
 - **Set As** to set it as a wallpaper or a picture ID.
 - **Send** to send it as a picture message.

Turning Bluetooth On/Off

1.  Tap the **Apps** icon to view your apps.
2.  Tap the **Settings** icon.
3.  Find **Bluetooth** and tap the **On/Off** switch to turn it on or off.

Backup AssistantSM Plus

You can save your phone's address book to a secure website. If your phone is lost or damaged, or if you upgrade to a new phone,

Backup Assistant will restore your contacts. Go to verizonwireless.com/baplus.

NOTE: Subject to specific terms of use. See verizonwireless.com/baplus for details.

Internet

Take the Internet with you on the go. You can reach the latest news, weather and stock reports from your phone.

1.  Tap the **Apps** icon to view your apps.
2.  Tap the **Browser** icon to start surfing the web.

Support & More

My Verizon

 Manage your account, track your usage, edit account information, pay your bill and more at verizonwireless.com/myverizon.

Customer Service

 Call (800) 922-0204. Follow us @VZWSupport. 

More Information

 Download a User Guide from support.vzw.com/phones or call (877) 268-7589 to order a copy.

Customer Information

Your Wireless Device and Third Party Services

Verizon Wireless is the mobile carrier associated with this wireless device, but many services and features offered through this wireless device are provided by or in conjunction with third parties. Verizon Wireless is not responsible for your use of this wireless device or any non-Verizon Wireless applications, services and products including any personal information you choose to use, submit or share with others. Specific third party terms and conditions, terms of use, and privacy policies shall apply. Please review carefully all applicable terms and conditions and policies prior to using this wireless device and any associated application, product or service.

Hearing Aid Compatibility Information

This phone has been tested and rated for use with hearing aids for some of the wireless technologies that it uses. However, there may be some newer wireless technologies used in this phone that have not been tested yet for use with hearing aids. It is important to try the different features of this phone thoroughly and in different locations, using your hearing aid or cochlear implant, to determine if you hear any interfering noise. Consult your service provider or the manufacturer of this phone for information on hearing aid compatibility. If you have questions about return or exchange policies, consult your service provider or phone retailer.